

GN Adapter

Kompatibilität Mobiltelefone

Artikel	Marke	Model
GN209751	Motorola	RAZRV3 / V3x / V3i / PEBLU6 / E770 / SLVRL6 / L7 / E1070 / BLK/Rarz V3c / L2 / KRZRK1 / Z3 / RAZRMAXX RAZRV3XX / RAZR / V360 / A910 / RIZR Z6 / Z8 / E770V / E6 / W218 / W360 / KRZR K3 / MAXX V6
GN106751	Nokia	252 / 1100 / 1101 / 1108 / 1110 / 1112 / 1600 / 2100 / 2300 / 2600 / 2610 / 2650 / 2652 / 3210 / 3310 / 3315 / 3330 / 3360 3390 / 3410 / 3510 / 3510i / 3590 / 3610 / 3650 / 3660 / 5210 / 5510 / 6030 / 6060 / 6236i / 6510 / 6590 / 6600 / 7280 7380 / 7390 / 7650 / 8210 / 8250 / 8260 / 8290 / 8310 / 8390 / 8800 / 8801 / 8850 / 8855 / 8890 / 8910 / 8910i / N-qage
GN108751	Nokia	3285 / 3530 / 5110 / 5130 / 5120 / 5160 / 5190 / 6110 / 6120 / 6150 / 6160 / 6161 / 6162 / 6190 / 6210 / 6250 / 6310 / 6310i 6340 / 6370 / 7100 / 7110 / 7190 / RinGo
GN108752	Nokia	6250
GN110751	Nokia	2652 / 2626 / 3100 / 3108 / 3120 / 3200 / 3205 / 3220 / 3230 / 3250 / 3300 / 5100 / 5140 / 5140i / 6020 / 6021 / 6070 6100 / 6101 / 6103 / 6108 / 6111 / 6125 / 6131 / 6136 / 6170 / 6220 / 6225 / 6230 / 6230i / 6233 / 6234 / 6260 / 6270 6280 / 6585 / 6610 / 6610i / 6620 / 6630 / 6650 / 6670 / 6680 / 6681 / 6800 / 6810 / 6820 / 6822 / 7200 / 7210 / 7250 7250i / 7260 / 7270 7360 / 7370 / 7600 / 7610 / 7700 / 7710 / 9300 / 9300i / 9500 / N70 / N71 / N80 / N90 / N92 / E60 E61 / E61i / E65 / E70 N93 / N93i / N73 / N76 / E50 / 7373 / 6290 / 6086 / 6120C / N80i
GN355751	Panasonic	30 / 50 / 70 / 90
GN360751	Samsung	D307 / D500 / D508 / D600 / D730 / E300 / E315 / E316 / E317 / E340 / E350 / E530 / E568 / E610 / E620 / E630 / E635 E720 / E728 / E730 / E738 / E760 / E780 / E800 / E820 / E850 / E880 / Z107 / Z110 / Z130 / Z140 / Z300 / Z320i / Z500 ZV10 / ZM60 / P207 / P730 / P735 / P777 / S341i / S342i / X138 / X140 / X620 / X660 / X680 / i300 / E770 / E370 / SGH X700 / P200 / P300 / i320 / E840
GN361751	Samsung	D800
GN410751	Siemens	A52 / A55 / A56 / A57 / A60 / A62 / A65 / A70 / A75 / AX72 / AX75 / C6 / C50 / C55 / C56 / C60 / C61 / C62 / C65 / C72 C75 / CT56 / CF62 / CF63 / CF75 / CL65 / CL75 / CX65 / CX70 / CX75 / CXV65 / CV65 / CFX65 / CF110 / CT66 / SX1 S55 / S56 / S57 / S65 / S66 / S75 / SL55 / SL56 / SL65 / SL75 / ST60 / SF65 / SK65 / SP65 / SXG75 / M55 / M56 / M65 M75 / MC60 / ME75 / MCT62 / Xelibri 1 / Xelibri 2 / Xelibri 3 / Xelibri 4 / Xelibri 5 / Xelibri 6 / Xelibri 7 / Xelibri 8
GN405751	Siemens	C/S 25 / A / C / M / S 35 / SL 42 / C/S 45
GN157751	Ericsson	6 / 7 / 8 / 1018 / R250 / T10 / 18
GN152751	Sony Ericsson	T20e / T20S / T28 / T29 / T38 / T39m / T60 / T61Z / T62 / T68 / T65 / T66 / T67 / T68i / T100 / T102 / T105 / T106 / T200 T202 / T206 / T226 / T230 / T237 / T238 / T300 / T302 / T306 / T310 / T312 / T316 / T320 / T600 / T606 / T608 / T610 T616 / T618 / T628 / / T630 / T637 / R290 / R310 / R300Z / R300Lx / R320 / R380 / R520m / R520 / R600 / A2218 A2218Z / A2288 / A2618 / A2628 / A3618 / Z200 / Z300i / Z208 / Z500 / Z600 / Z608 / Z630 / Z700 / Z800i / Z1010 / S700 S700i / S710 / P800 / P802 / P900 / P908 / P910 / P910i / K300i / F500i / K300i / K500i / K506c / K508i / K508c / K600i K608i / K700 / K700i / J200c / J200i / J300i / T290i / V600i / V800 / J210i / W600i
GN153751	Sony Ericsson	K310i / K610i / K750i / D750i / S600i / W200i / W300i / W550i / W610i / W660 / W700i / W800i / W810i / W900i / W910 W950i / W960 / P990i / J100i / J220i / J230i / M600i / Z200i / Z310i / Z320i / Z520i / Z530i / Z550i / Z710i / W850i / W710i k510i / K550i / K290i / K630i / V630i / K770i / K790i / K800i / K810i / K510i / V630 / Z558i / Z610i / K850i / P1i / T650i V640i